

Instructions

EVEN BETTER

Accoustical Coating



Installation

Surfaces should be clean from dust, dirt, grease, particles etc. prior to spraying.

- 1 Mix thoroughly before use.
- 2 Use spray gun with 5/11 to 5/15 nozzle, pressure >100 bar (>1500 Psi).
Spray a thin layer, let dry.
- 3 Spray additional layers if needed.
Estimated drying time 20-30 minutes. The product will be completely cured after 24-48 hours.

Handling information: Airways can be irritated when spraying, use protective mask to prevent this. To avoid spray dust in your eyes, use protective glasses.

Coverage: If the products is applied in 2 layers, 19 liters (5 U.S. gallons) will cover approximately 80-100 m2 (approx. (800-1000 sq.ft.).

Storage

Store dry and keep away from direct sunlight. Avoid freezing.

